

# HydroMinder WDP

Adjustable Pump – BSP



| Description              | Product code |
|--------------------------|--------------|
| HydroMinder WDP 0.2 - 2% | 117957CW     |
| HydroMinder WDP 0.8 - 5% | 117958CW     |

## Maintenance Kits

### Kit A: Dosage gasket kit

Dosage gasket



#### Light Usage:

Change every 6-12 months

#### Medium Usage:

Change every 6 months

#### Heavy Usage:

Change every 3-4 months

| Model                    | Product code |
|--------------------------|--------------|
| HydroMinder WDP 0.2 - 2% | 017210CW     |
| HydroMinder WDP 0.8 - 5% | 017220CW     |

### Kit B: Wear kit

Dosing gasket,  
shaft



Change  
as needed

| Model                    | Product code |
|--------------------------|--------------|
| HydroMinder WDP 0.2 - 2% | 017211CW     |
| HydroMinder WDP 0.8 - 5% | 017221CW     |

### Kit D: Check valve kit

Suction tube fitting  
assembly (poppet,  
O-ring, spring, fitting)



Change  
as needed

| Model                    | Product code |
|--------------------------|--------------|
| HydroMinder WDP 0.2 - 2% | 017213CW     |
| HydroMinder WDP 0.8 - 5% | 017223CW     |

### Kit E: Wear parts maintenance kit

Inner cylinder, shaft and  
check valve



Change  
as needed

| Model                    | Product code |
|--------------------------|--------------|
| HydroMinder WDP 0.2 - 2% | 017214CW     |
| HydroMinder WDP 0.8 - 5% | 017224CW     |

### Kit G: Complete lower end kit

Dosing gasket, O-ring, shaft, gasket, inner cylinder and check valve, outer cylinder, ratio adjuster, O-rings, pin, filter, solution tube with strainer filter



Change as needed

| Model                    | Product code |
|--------------------------|--------------|
| HydroMinder WDP 0.2 - 2% | 017216CW     |
| HydroMinder WDP 0.8 - 5% | 017226CW     |

### Kit H: Motor piston kit

Motor piston assembly



Change as needed

| Model                    | Product code |
|--------------------------|--------------|
| HydroMinder WDP 0.2 - 2% | 017200XT     |
| HydroMinder WDP 0.8 - 5% | 017200XT     |

## Definitions

**Light Usage:** Pump is used once a week

**Medium Usage:** Pump is used 3-4 times each week

**Heavy Usage:** Pump is used 24 hours a day, seven days a week